How to adjust camera settings (MM core 6.0)

First option:

1. Tap on ☰ icon on the top left corner of the touchscreen.
2. Password to exit is **mm**.
3. Tap on **Submit** to exit.
4. You will reach the Magic Mirror launcher page.
5. Tap on **Setup**.

6. Select **Step 1: Camera**.
7. Camera setting page will be shown.
8. Adjust the **settings**.
9. **Test** and **Save**.

Second option:

1. Open a Magic Mirror module.
2. Press on "**Ctrl+Shift+C**" key on the keyboard.
3. Camera setting page will be shown.
4. Adjust the **settings**.
5. **Test** and **Save**.